

## How to Install PVC Fretwork Wall Panels


### Step 1 : Clean to Clear debris

Smooth installation surface with sandpaper by removing excessive bumps or texture. Wipe wall clean to clear debris.


### Step 2 : Mark the installation

We recommend laying out the desired layout before installation. Mark the installation points using a chalk line or straight edge and level.

A: For single panels, start at either the top or bottom corner at the edge of the wall and work towards the opposite corner.




B : For 2-piece panel sets start at the center and work out.



### Step 3 : Apply Adhesive

Apply a small amount of adhesive to the back of the panel and secure with small brad nails. (Follow adhesive manufacturer's instructions for proper application.)

A : Install panels side by side.





# DECORATIVE CEILING TILES

from plain to beautiful in hours

---

B : OR for a different look leave a gap between each panel.



## Safety Instructions

- Make sure to use the correct tools recommended.
- Wear proper protective gear.
- Follow fixture, power tools, paint manufacturers instructions, and users manuals.
- Use common sense and follow good construction practices.

## Tools & Materials Checklist

- Standard power grab adhesive
- Utility Knife, Circular Saw, or Table Saw
- 100% acrylic paint
- Power drill or hammer
- Fine sandpaper
- Small brad nails
- Chalk line and measuring tape

## Special Instruction and Notes

- It is highly recommended that you paint or finish the panels before installation.
- Recommended use of 100% acrylic latex paint for PVC products.
- Clean the installation surface and back of panel of any debris with a clean cloth.
- Make sure the surface and the back of the panel are completely dry before installation.
- Before installing, acclimate the PVC panels in the room where you will be installing them.
- In most applications you will have to trim some panels. Cut them with a standard utility knife or power tool, such as a table saw. Sand cut edge to remove debris.
- Depending on your installation method, use standard power grip adhesive and small brad nails.